



# VR-3X00-SBU(S)



**VR-3100-SBU(S), VR-3200-SBU(S)**

**User Guide**

**v1.2**

# 1. Overview

This phone is a full-feature telephone that provides voice communication. Read this QIG carefully to learn how to operate this product and take advantage of its features.

## Package Contents


When unpacking the phone, ensure all the following items are present and undamaged. If anything appears to be missing or broken, contact your dealer for a replacement.

1. **VR-3100-SBU(S) or VR-3200-SBU(S) Wi-Fi Handset phone**
2. **Charging Stand**
3. **Battery**
4. **AC/DC Adaptor**
5. **User Guide (This document)**

# 2. Product Description

The following contains important information to help you familiarize with the functions of the phone.


## Front View



item	Name	Description
1	Display screen	Capacitive touch display
2	Power key	Press to power on/off
3	Function key	
3-1	Home key	Press to return to idle page
3-2	Dial key	Press these keys to enter phone numbers
3-3	Service key	Press to enter service page
3-4	Dialing Instruction key	Press to enter Dialing Instructions page. Red LED turns on when handset is charging, Red LED turns off when handset is fully charged,
3-5	Volume -	Press to decrease the volume of the ringer tone or handset
3-6	Volume +	Press to increase the volume of the ringer tone or handset
3-7	Language key	Press to select display language


item	Name	Description
3-8	Message key	Press to listen to voice messages Red LED turns on when there is an unheard voice message

### Rear view



Name	Description
DC jack	Connects to AC/DC power adapter



### Side view



Name	Description
USB Charger ports	Connects to charging cable of mobile device.

## Battery Installation



The following illustration shows how to install the handset and battery.



# 3. Web Configuration

## Web Login

To setup the VR-3x00 handset from web configuration manually, boot the handset to the AP mode. Please remove the phone battery, press and hold the power button, and then install the battery. The VR-3x00 handset will startup and display its AP mode SSID, password and AP IP address. Please use your laptop to connect the VR-3x00 in AP mode. Connect the phone at <http://192.168.4.1:8000> via a web browser by using username/password as admin/1234.



After logging in, the system information shows as below.

System Status	
Status	FW Version : FW:v2.0.2 FS:01.0.03
WIFI	WIFI SSID : aruba-ap
VoIP	Provision IP: 192.168.168.128
Speed Dial	Provision File: 1379.cfg
System	Upgrade IP: http://192.168.168.128:69
	Upgrade FILE: vr3102.vb.vr3102.vi

## WIFI

Setup the Wi-Fi SSID, Password and the IP type.

WIFI Setup	
WIFI SSID:	<input type="text" value="FAE"/>
WIFI PASSWORD:	<input type="text" value="1234567890"/>
WIFI IP Type:	<input type="text" value="DHCP"/>
<input type="button" value="Submit"/>	

### WIFI SSID:

The WIFI SSID

### WIFI PASSWORD:

The WIFI Password

### WIFI IP Type:

Default is DHCP.

# VoIP

Setup the SIP account

VoIP Setup	
Switch :	Enable
Display name :	1361
User name :	1361
Authentication Name :	1361
Password :	1361
Register Domain :	192.168.168.249
Register IP :	192.168.168.249:5060
Register Backup Domain :	
Register Backup IP :	
First Codec :	G.711 U
Second Codec :	G.711 A
Frame Size :	20 ms
2833 Payload :	101
SIP Local Port :	5060
RTP Port :	42000
Expire :	300
MWI :	Disable
DNS SRV :	Disable
Keep Alive :	Disable
DTMF Type :	RFC 2833
Caller ID :	Disable
Submit	

## Switch:

Check "Enable" to enable SIP registration or "Disable" to disable the SIP account temporarily.

## Display Name:

Display Name is the name of the phone or the location of the phone on the remote party.

## User name:

User name of the SIP account, also known as user ID or extension number.

## Authentication Name:

Authentication Name is for SIP authentication.

## Password:

Password of the SIP account

## Register Domain:

FQDN, SIP domain name or IP address of the SIP server

For example, voip.aeicomcommunications.com or 172.8.12.11

## Register IP:

IP address of the SIP Server

If the listening port of the SIP Server is different from 5060, please add the port to at end of address. For example, 172.8.12.11:5061

## Register Backup Domain:

IP address of the secondary SIP server

For example, 172.8.12.12

**Register Backup IP:**

IP address of the secondary SIP Server  
For example, 172.8.12.12

**Codec Priority:**

Select the 2 codec priority.

**Frame Size:**

Frame size for G711u and G711a.  
G711 ranges from 20ms and 40ms.

**2833 Payload:** (Default, 101)

DTMF RFC2833 Payload Type, ranging from 96 ~ 127

**SIP Local Port:** (Default, 5060)

SIP Local port

**RTP Port Base:** (Default, 42000)

The port of RTP starts

**Expire:** (Default, 600)

SIP registration expire time (seconds); select from 60, 120, 300 and 600

**MWI:** (Default, Disable)

Enable to subscribe message waiting information.

**DNSSRV:** (Default, Disable)

Enable DNSSRV query

**Keep Alive:** (Default, Disable)

Send keep alive package to keep the SIP registration from being blocked

**DTMF Type:** (Default, RFC 2833)

DTMF for transmitting digits, \* and #; select from RFC2833, SIP Info and In Band

**Caller ID:** (Default, Disable)

Display the caller id of an incoming call

## Speed Dial

The screenshot shows the 'VoIP Setup' interface. On the left, there is a navigation menu with links for 'Status', 'WIFI', 'VoIP', 'Speed Dial', and 'System'. The main area contains ten rows, each representing a speed dial entry. Each row has a label (e.g., 'Speed Dial 1. :') and a text input field. The values in the input fields are: 1611, 1569, 1688, 1688, 1688, 1688, 1688, 1688, 1688, and 1611. A 'Submit' button is located at the bottom right of the form.

Speed Dial	Value
Speed Dial 1. :	1611
Speed Dial 2. :	1569
Speed Dial 3. :	1688
Speed Dial 4. :	1688
Speed Dial 5. :	1688
Speed Dial 6. :	1688
Speed Dial 7. :	1688
Speed Dial 8. :	1688
Speed Dial 9. :	1688
Speed Dial 10. :	1611

SPEED DIAL 1 ~ 9: 9 touch screen service keys.

SPEED DIAL 10: Message key

## System

The screenshot shows the 'System Setup' interface. On the left, there is a navigation menu with links for 'Status', 'WIFI', 'VoIP', 'Speed Dial', and 'System'. The main area contains several configuration options, each with a label and a control element (text input or dropdown menu). The options are: 'Auto Upgrade' (set to 'Enable'), 'Provision Server' (192.168.168.128), 'Provision File' (1379), 'Upgrade Protocol' (set to 'TFTP'), 'Upgrade Server' (192.168.168.128), 'Firmware' (vr3102.vb), and 'Partition' (vr3102.vi). A 'Submit' button is located below these options. At the bottom, there are two more options: 'Reboot' (set to 'Reboot') and 'Default' (set to 'Default').

Auto Upgrade:	Enable
Provision Server:	192.168.168.128
Provision File:	1379
Upgrade Protocol:	TFTP
Upgrade Server:	192.168.168.128
Firmware:	vr3102.vb
Partition:	vr3102.vi
Reboot:	Reboot
Default:	Default

### Server:

The IP address information of the server, for example, 192.168.1.54. The phone will retrieve the .cfg file.

### Provision File:

The name(room number) of the provision file in the root folder of the server.  
For example,1234: 1234.cfg

Empty MAC.cfg

**Upgrade Protocol:** (Default, TFTP)



## 4. Phone setup

At dialing page  , press [**\*\*6862\***  ] to enter system setup menu.

1. Network status  
Display network relative information: MAC address, access point SSID, IP address, and Wi-Fi status.
2. VoIP status  
Display SIP registration status and extension number.
3. Upgrade APP  
Update system firmware (fixed by Auto Provision setting).
4. Upgrade DATA  
Update system partition (fixed by Auto Provision setting).
5. Wi-Fi AP Scan  
Scan nearby APs, select desired AP and enter password to connect.  
\* Press [?]123] or [ABC]to switch between number and alphabet.
6. Factory Reset  
Reset phone to factory default.
7. Exit  
Exit system setup menu.

## 5. Provisioning

1. Provision config file (\*.cfg)

Sample provision config file:

```
[INFO]
MODEL=VR3100

[SIP_ACCOUNT]
SWITCH=1
USER_NAME=1234
DISPLAY_NAME=1234
AUTH_NAME=1234
PASSWORD=1234
REGIST_SERVER=192.168.168.253:5070
REALM=192.168.168.253:5070
MWI=0
EXPIRE_TIME=600
DTMF_TYPE=RFC2833
SEND_ALIVE=0
DNSSRV=0

[SPEED_DIAL]
0=1000
1=1001
2=1002
3=1003
4=1004
5=1005
```

```
6=1006
7=1007
8=1008
9=999

[AUTO_UPGRADE]
PROTOCOL=TFTP
SERVER_IP=192.168.168.253
PORT=69
FIRMWARE=vr3100
PARTITION=vr3100

[SIP_GLOBAL]
LISTEN_PORT=5060
RTP_PORT=10000
PRIMARY_CODEC=G.711 uLaw
SECONDARY_CODEC=G.711 aLaw
RFC2833_TYPE=101
LOG_SERVER=192.168.168.253
CALLER_ID=0
```



After editing, save the config file name as [MAC Address] or [Room number].

MAC Address 00:11:22:33:44:55, config file name: 001122334455.cfg

Or

Room number 1234, config file name: 1234.cfg

## 2. Provision Server IP setting

At dialing page , press [**\*\*6861\*(Server IP)#**  ].

Provision server supports TFTP and HTTP (port 6122).

For example: press [**\*\*6861\*192\*168\*168\*253#**  ] to set provision server IP: 192.168.168.253

\*TFTP is default protocol.

\*\*Provision files must be under TFTP / HTTP Server root directory.



## 3. Provision file type setting

The phone supports two file types: MAC address or Room number.

At dialing page , press [**\*\*6862\*#**  ] to use MAC address type config files.

At dialing page , press [**\*6862\*(room number)#**  ] to use Room number type config files

## 4. Wi-Fi Phone provisioning

After connecting to internet and setting up provision server/config file type, press [**\*\*6868\***  ] at dialing page 

Wi-Fi phone will restart and execute provisioning to complete phone settings.

## 6. Summary of system commands


At dialing page , press following and  to execute commands.

**6862*	Enter system setup menu
**6863*	Input WIFI SSID and Password
**6865*	Display firmware version
**6866*	Display MAC address
**6867*	<p>Init Sync</p> <p>sync the phone settings (WIFI SSID, WIFI password, provision server) from other configured phones</p> <p>Step1: Configure the 1<sup>st</sup> phone from web interface: WIFI setting, provision server and make sure the 1<sup>st</sup> phone is able to connect to the WIFI AP and download configuration file.</p> <p>Step2: Remove the battery of 1<sup>st</sup> phone, press and hold the power button , and then reinstall the battery. The 1<sup>st</sup> phone will boot to AP mode</p> <p>Step3: Press **6867*# and select OK on the 2<sup>nd</sup> phone. The 2<sup>nd</sup> phone will auto connect to the 1<sup>st</sup> phone and sync the WIFI SSID, WIFI password, provision server from the 1<sup>st</sup> phone , once phone got WIFI connection , phone will show status on screen .</p> <p>Step4: Reboot the 2<sup>nd</sup> phone. The 2<sup>nd</sup> phone with connect to the WIFI AP and download provision file.</p>
**6868*	Restart phone set
**6861*192*168*168*253#	Set provision server IP to 192.168.168.253
**6862*888#	Auto provision use 888 room number config file type
**6862*#	Auto provision use 888 room MAC config file type

## 7. Operations


### Answering a Call

An incoming call is indicated by a ringing tone. You can answer the call by doing one of the followings:

- Press the **dial** key  on the handset to answer the call.

### Making a Call

Press dial key for numerical keypad.

- Press to enter the telephone number with green **dial** key  to make a call..


### Using the service function

To use the pre-assigned service function for the most commonly dialed numbers. Use the function to dial a number quickly, instead of keying in a complete number.

- Press **service** key 
- Tap the icon to call desired service.

### Charging the Handset Battery

You would need to charge the handset battery before using the handset.

- Install the battery into the handset.
- Place the handset onto the base unit and base unit will start to charge the handset automatically.
- This icon  will show charging progress.

## 8. Support

For technological support, please email to [support@aeicommunication.com.tw](mailto:support@aeicommunication.com.tw)

# Record of Revision

Date	ver.	Description
2019/11/25	1.0	First issue
2022/9/16	1.1	Update for firmware v2.02
2023/2/22	1.2	Update display function keys