Analog Phone

AGR-6109-S / AGR-6106-S



QIG v1.0

1 Over view

This phone is a full-feature telephone that provides voice communication. Read this QIG carefully to learn how to operate this product and take advantage of its features.

Package Contents

When unpacking the phone, ensure all the following items are present and undamaged. If anything appears to be missing or broken, contact your dealer for a replacement.

- 1. Base Unit
- 2. Corded Handset
- 3. Stand
- 4. Quick Installation Guide (This document)

2 Product Description

The following contains important information to help you familiarize with the functions of the Analog phone.

Front View




	Name	Description
1	Ring Indicator	A red light indicator means that you have incoming calls or signals that a message is waiting for retrieval.
2	Dialing Pad	Press the buttons to dial a phone number or enter alphabetical characters.
3	Speed dial keys	Press to dial one touch of Nine guest services or PBX features. Programmed during installation.
4	Mute key	Press to mute MIC.
5	Speaker	Press to start talk without handset.
6	Volume	Press to increase or decrease the volume of the ringer tone or speakerphone.

Connecting the Phone

The following illustration shows how to connect the Line Jack of Analog phone.



The following illustration shows how to install the phone and stand.



3 Operations

Answering a Call

An incoming call is indicated by a ringing tone and a flashing indicator at the top of both handset and base units. You can answer the call by doing one of the followings:

- Pick up the **handset** to answer the call.
- Press the **Speaker key** on the base to answer the call.

Making a Call

Dialing with the Keypad

• Enter the telephone number with the alphanumerical keypad and the call will start automatically.

Using the Speed dial keys

You can use the 9 pre-assigned speed dial hotkeys, to configure the most commonly dialed numbers. Use the function to dial a number quickly, instead of keying in a complete number.

To call a number using speed dialing, follow the steps below:

• Press the speed dial hotkey that has been pre-assigned to the phone number and the call will start automatically.

Using the Speaker Phone

For hands free operation, you can use the built-in speaker to talk on the phone. To use the speakerphone, follow the steps below:

- While talking on the phone, press the SPEAKER key on the phone to enable the Speakerphone function.
- Press Speaker key again to terminate the call.

Checking Voice Messages

If the **message waiting indicator** at top of handset or base unit lights up in red, it indicates that there are one or more new messages in voicemail box.

• Call Hotel services to retrieve voice messages.

For technical support, please email to support@aeicommunications.com.tw